

Safety information

Warning! To prevent fire or shock hazards, do not expose this unit to rain or moisture. Also do not use this unit's polarized plug with an extension cord receptacle or other outlets unless the prongs can be fully inserted. Refrain from opening the cabinet as there are high voltage components inside. Refer servicing to qualified service personnel.

Caution: to reduce the risk of electric shock, make sure power cords is unplugged from wall socket. To fully disengage the power to the unit, please disconnect the power cord from the AC outlet. Do not remove cover (or back). No user servicable parts inside. Refer to servicing to qualified service personnel.

DO NOT clean with benzene thinner, alkaline detergent, alcoholic system detergent, wax, polish cleaner, soap powder or insecticide. Rubber or vinyl should not be in contact with the cabinet for an extended period of time. These types of fluids and materials can cause paint to deteriorate, crack or peel.

Please use the power cord provided with this display in accordance with the table below. If a power cord is not supplied with this equipment, please contact the reseller. For all other cases, please use the power cord with the plug style that matches the power socket where the monitor is located.

The compatible power cord corresponds to the AC voltage of the power outlet and has been approved by, and complies with, the safety standards in the country of purchase. This equipment is designed to be used with a power cord that has a protective earth pin connected to earth. If the power cord is not connected to the earth, it may cause electric shock.

Please make sure the power cord is earthed properly

Plug Type	North America		European Continental	U.K.
Plug Shape				
Region	U.S.A./ Canada	Taiwan	EU	U.K.
Voltage	120*	110	230	230